



**PISTON - PISTONE  $\varnothing$  15**

MODEL:  
W130-150-170-950-951-952-953  
WW116-136-156-176-186-960-961-962

KIT N.	KIT 23	KIT 123	KIT 124
Positions Included	17	4-5-6 7-8- (11)	9-10
Posizioni Include			
N. pcs.	3	6	6

KIT 88	KIT 89	KIT 90	KIT 125	KIT 130
43-44 51	42	45	40-41	40-41 42-43 44-45 51
3	3	6	3	1

**PISTON - PISTONE  $\varnothing$  18**

MODEL:  
W97-112-124-140-154-954-955  
956-957-958-959

KIT 126	KIT 127	KIT 128	KIT 129	KIT 131
40-41	43-44 51	42	45	40-41 42-43 44-45 51
3	3	3	6	1

**STANDARD  
VERSION**

W97	W154	W954	WW116	WW961
W112	W170	W955	WW136	WW962
W124	W950	W956	WW156	
W130	W951	W957	WW176	
W140	W952	W958	WW186	
W150	W953	W959	WW960	